




Deployment Information

Your Trustgrid nodes are pre-configured and require only a few easy steps to get them online. If you have any trouble deploying the nodes, or if you have questions, reach out to Trustgrid support and we'll be happy to assist you with getting your nodes up and running ASAP.

Connectivity Example



What's In The Box?

- 2x Trustgrid Nodes
- 2x Network Cables
- 2x Power Supplies
- 2x Rack Mount Kits (If Applicable)

Before You Begin

- If you have a firewall between the Trustgrid nodes and the internet, and you firewall outbound traffic to the internet you will need to be sure the necessary firewall rules are in place to allow the required traffic. Please see the Frequently Asked Questions document for the rules and contact the Trustgrid provisioning team with questions.
- If your environment involves multiple VLANs, prepare the desired switch ports to allow access to the correct VLAN.

Deployment Steps

1. After unboxing the nodes, connect LAN1 port of each node to the outside/internet facing network. Connect LAN2 to the internal facing network.
2. Connect the power supplies for both nodes to the node and the desired power outlet.
3. If additional assistance is required, please contact Trustgrid.

Support Information

Feel free to reach out to us with any questions at:
Trustgrid Provisioning at provisioning@trustgrid.io

About Trustgrid

Trustgrid enables fast, simple, and secure connectivity to data. Quickly and securely connect applications to sensitive data sources, in real-time, anywhere, at scale. Guarantee the highest levels of security, compliance, and uptime.